SECTION 263213.16 - GASEOUS EMERGENCY ENGINE GENERATORS

PART 1 - GENERAL

1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

1.2 SUMMARY

- A. Section includes packaged engine generators for emergency use with the following features:
 - 1. Natural gas engine.
 - 2. Gaseous fuel system.
 - 3. Control and monitoring.
 - 4. Generator overcurrent and fault protection.
 - 5. Generator, exciter, and voltage regulator.
 - 6. Outdoor engine generator enclosure.
 - 7. Remote radiator motors.
 - 8. Vibration isolation devices.
 - 9. Finishes.

B. Related Requirements:

1. Section 263600 "Transfer Switches" for transfer switches including sensors and relays to initiate automatic-starting and -stopping signals for engine generators.

1.3 DEFINITIONS

- A. EPS: Emergency power supply.
- B. EPSS: Emergency power supply system.
- C. Operational Bandwidth: The total variation from the lowest to highest value of a parameter over the range of conditions indicated, expressed as a percentage of the nominal value of the parameter.

1.4 ACTION SUBMITTALS

- A. Product Data: For each type of product.
 - 1. Include rated capacities, operating characteristics, electrical characteristics, and furnished specialties and accessories.
 - 2. Include thermal damage curve for generator.
 - 3. Include time-current characteristic curves for generator protective device.
 - 4. Include fuel consumption in cubic feet per hour at 0.8 power factor at 0.5, 0.75, and 1.0 times generator capacity.
 - 5. Include generator efficiency at 0.8 power factor at 0.5, 0.75, and 1.0 times generator capacity.

- 6. Include airflow requirements for cooling and combustion air in cubic feet per minute at 0.8 power factor, with air-supply temperature of 95, 80, 70, and 50 deg F. Provide Drawings indicating requirements and limitations for location of air intake and exhausts.
- 7. Include generator characteristics, including, but not limited to, kilowatt rating, efficiency, reactances, and short-circuit current capability.

B. Shop Drawings:

- 1. Include plans and elevations for engine generator and other components specified.
- 2. Include details of equipment assemblies. Indicate dimensions, weights, loads, required clearances, method of field assembly, components, and location and size of each field connection.
- 3. Identify fluid drain ports and clearance requirements for proper fluid drain.
- 4. Design calculations for selecting vibration isolators and seismic restraints and for designing vibration isolation bases.
- 5. Vibration Isolation Base Details: Detail fabrication, including anchorages and attachments to structure and supported equipment. Include base weights.
- 6. Include diagrams for power, signal, and control wiring. Complete schematic, wiring, and interconnection diagrams showing terminal markings for EPS equipment and functional relationship between all electrical components.

1.5 INFORMATIONAL SUBMITTALS

- A. Qualification Data: For manufacturer.
- B. Seismic Qualification Data: Certificates, for engine generator, accessories, and components, from manufacturer.
 - 1. Basis for Certification: Indicate whether withstand certification is based on actual test of assembled components or on calculation.
 - 2. Dimensioned Outline Drawings of Equipment Unit: With engine and generator mounted on rails, identify center of gravity and total weight, supplied enclosure, and each piece of equipment not integral to the engine generator, and locate and describe mounting and anchorage provisions.
 - 3. Detailed description of equipment anchorage devices on which the certification is based and their installation requirements.
- C. Source Quality-Control Reports: Including, but not limited to, the following:
 - 1. Certified summary of prototype-unit test report.
 - 2. Certified Test Reports: For components and accessories that are equivalent, but not identical, to those tested on prototype unit.
 - 3. Certified Summary of Performance Tests: Certify compliance with specified requirement to meet performance criteria for sensitive loads.
 - 4. Report of factory test on units to be shipped for this Project, showing evidence of compliance with specified requirements.
 - 5. Report of sound generation.
 - 6. Report of exhaust emissions showing compliance with applicable regulations.
 - 7. Certified Torsional Vibration Compatibility: Comply with NFPA 110.
- D. Field quality-control reports.
- E. Warranty: For special warranty.

1.6 CLOSEOUT SUBMITTALS

- A. Operation and Maintenance Data: For packaged engine generators to include in emergency, operation, and maintenance manuals.
 - 1. In addition to items specified in Section 017823 "Operation and Maintenance Data," include the following:
 - a. List of tools and replacement items recommended to be stored at Project for ready access. Include part and drawing numbers, current unit prices, and source of supply.
 - b. Operating instructions laminated and mounted adjacent to generator location.
 - c. Training plan.

1.7 MAINTENANCE MATERIAL SUBMITTALS

- A. Furnish extra materials that match products installed and that are packaged with protective covering for storage and identified with labels describing contents.
 - 1. Fuses: One for every 10 of each type and rating, but no fewer than one of each.
 - 2. Indicator Lamps: Two for every six of each type used, but no fewer than two of each.
 - 3. Filters: One set each of lubricating oil, fuel, and combustion-air filters.
 - 4. Tools: Each tool listed by part number in operations and maintenance manual.

1.8 QUALITY ASSURANCE

- A. Installer Qualifications: An authorized representative who is trained and approved by manufacturer.
- B. Testing Agency Qualifications: Accredited by NETA.
 - 1. Testing Agency's Field Supervisor: Certified by NETA to supervise on-site testing.

1.9 WARRANTY

- A. Manufacturer's Warranty: Manufacturer agrees to repair or replace components of packaged engine generators and associated auxiliary components that fail in materials or workmanship within specified warranty period.
 - 1. Warranty Period: 2 years from date of Substantial Completion.

PART 2 - PRODUCTS

2.1 MANUFACTURERS

A. Source Limitations: Obtain packaged engine generators and auxiliary components from single source from single manufacturer.

2.2 PERFORMANCE REQUIREMENTS

- A. Seismic Performance: Engine generator housing, engine generator, batteries, battery racks, silencers, sound attenuating equipment, accessories, and components shall withstand the effects of earthquake motions determined according to ASCE/SEI 7.
 - 1. The term "withstand" means "the unit will remain in place without separation of any parts when subjected to the seismic forces specified."
 - 2. Shake-table testing shall comply with ICC-ES AC156. Testing shall be performed with all fluids at worst-case normal levels.
 - 3. Component Importance Factor: 1.5.
- B. B11 Compliance: Comply with B11.19.
- C. NFPA Compliance:
 - 1. Comply with NFPA 37.
 - 2. Comply with NFPA 70.
 - 3. Comply with NFPA 99.
 - 4. Comply with NFPA 110 requirements for Level 1 EPSS.
- D. UL Compliance: Comply with UL 2200.
- E. Engine Exhaust Emissions: Comply with EPA Tier 2 requirements and applicable state and local government requirements.
- F. Noise Emission: Comply with applicable state and local government requirements for maximum noise level at adjacent property boundaries due to sound emitted by engine generator, including engine, engine exhaust, engine cooling-air intake and discharge, and other components of installation.
- G. Environmental Conditions: Engine generator system shall withstand the following environmental conditions without mechanical or electrical damage or degradation of performance capability:
 - 1. Ambient Temperature: 41 to 104 deg F.
 - 2. Relative Humidity: Zero to 95 percent.
 - 3. Altitude: Sea level to 1000 feet.

2.3 ENGINE GENERATOR ASSEMBLY DESCRIPTION

- A. Factory-assembled and -tested, water-cooled engine, with brushless generator and accessories.
- B. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, by a qualified testing agency, and marked for intended location and use.
- C. EPSS Class: Engine generator shall be classified as Class 96 according to NFPA 110.
- D. Induction Method: Naturally aspirated.
- E. Governor: Adjustable isochronous, with speed sensing.
- F. Mounting Frame: Structural-steel framework to maintain alignment of mounted components without depending on concrete foundation. Provide lifting attachments sized and spaced to prevent deflection of base during lifting and moving.

1. Rigging Diagram: Inscribed on metal plate permanently attached to mounting frame to indicate location and lifting capacity of each lifting attachment and engine generator center of gravity.

G. Capacities and Characteristics:

- 1. Power Output Ratings: Nominal ratings as indicated at 0.8 power factor excluding power required for the continued and repeated operation of the unit and auxiliaries, with capacity as required to operate as a unit as evidenced by records of prototype testing.
- 2. Nameplates: For each major system component to identify manufacturer's name and address, and model and serial number of components.

H. Engine Generator Performance:

- 1. Steady-State Voltage Operational Bandwidth: 3 percent of rated output voltage, from no load to full load.
- 2. Transient Voltage Performance: Not more than 20 percent variation for 50 percent step-load increase or decrease. Voltage shall recover and remain within the steady-state operating band within three seconds.
- 3. Steady-State Frequency Operational Bandwidth: 0.5 percent of rated frequency, from no load to full load
- 4. Steady-State Frequency Stability: When system is operating at any constant load within the rated load, there shall be no random speed variations outside the steady-state operational band and no hunting or surging of speed.
- 5. Transient Frequency Performance: Less than 5 percent variation for 50 percent step-load increase or decrease. Frequency shall recover and remain within the steady-state operating band within five seconds.
- 6. Output Waveform: At no load, harmonic content measured line to line or line to neutral shall not exceed 5 percent total and 3 percent for single harmonics. Telephone influence factor, determined according to NEMA MG 1, shall not exceed 50 percent.
- 7. Sustained Short-Circuit Current: For a three-phase, bolted short circuit at system output terminals, system shall supply a minimum of 250 percent of rated full-load current for not less than 10 seconds and then clear the fault automatically, without damage to generator system components.
- 8. Start Time: Comply with NFPA 110, Type 10, system requirements.

I. Engine Generator Performance for Sensitive Loads:

- 1. Oversizing generator compared with the rated power output of the engine is permissible to meet specified performance.
 - a. Nameplate Data for Oversized Generator: Show ratings required by the Contract Documents rather than ratings that would normally be applied to generator size installed.
- Steady-State Voltage Operational Bandwidth: 1 percent of rated output voltage, from no load to full load.
- 3. Transient Voltage Performance: Not more than 10 percent variation for 50 percent step-load increase or decrease. Voltage shall recover and remain within the steady-state operating band within 0.5 second.
- 4. Steady-State Frequency Operational Bandwidth: Plus, or minus 0.25 percent of rated frequency, from no load to full load.
- 5. Steady-State Frequency Stability: When system is operating at any constant load within the rated load, there shall be no random speed variations outside the steady-state operational band and no hunting or surging of speed.

- 6. Transient Frequency Performance: Less than 2-Hz variation for 50 percent step-load increase or decrease. Frequency shall recover and remain within the steady-state operating band within three seconds.
- 7. Output Waveform: At no load, harmonic content, measured line to neutral, shall not exceed 2 percent total with no slot ripple. Telephone influence factor, determined according to NEMA MG 1, shall not exceed 50 percent.
- 8. Sustained Short-Circuit Current: For a three-phase, bolted short circuit at system output terminals, system shall supply a minimum of 300 percent of rated full-load current for not less than 10 seconds and then clear the fault automatically, without damage to winding insulation or other generator system components.
- 9. Excitation System: Performance shall be unaffected by voltage distortion caused by nonlinear load.
 - a. Provide permanent magnet excitation for power source to voltage regulator.
- 10. Start Time: Comply with NFPA 110, Type 10, system requirements.
- J. Parallel Engine Generators:
 - 1. Automatic reactive output power control and load sharing between engine generators operated in parallel.
 - 2. Automatic regulation, automatic connection to a common bus, and automatic synchronization, with manual controls and instruments to monitor and control paralleling functions.
 - 3. Protective relays required for equipment and personnel safety.
 - 4. Paralleling suppressors to protect excitation systems.
 - 5. Reverse power protection.
 - 6. Loss of field protection.

2.4 ENGINE

- A. Fuel: Natural gas.
- B. Rated Engine Speed: 1800 rpm.
- C. Lubrication System: Engine or skid mounted.
 - 1. Filter and Strainer: Rated to remove 90 percent of particles 5 micrometers and smaller while passing full flow
 - 2. Thermostatic Control Valve: Control flow in system to maintain optimum oil temperature. Unit shall be capable of full flow and is designed to be fail-safe.
 - 3. Crankcase Drain: Arranged for complete gravity drainage to an easily removable container with no disassembly and without use of pumps, siphons, special tools, or appliances.
- D. Jacket Coolant Heater: Electric-immersion type, factory installed in coolant jacket system. Comply with NFPA 110 requirements for Level 1 equipment for heater capacity and with UL 499.
- E. Cooling System: Closed loop, liquid cooled, with radiator factory mounted on engine generator mounting frame and integral engine-driven coolant pump.
 - 1. Coolant: Solution of 50 percent ethylene-glycol-based antifreeze and 50 percent water, with anticorrosion additives as recommended by engine manufacturer.
 - 2. Size of Radiator: Adequate to contain expansion of total system coolant, from cold start to 110 percent load condition.

- 3. Expansion Tank: Constructed of welded steel plate and rated to withstand maximum closed-loop coolant-system pressure for engine used. Equip with gage glass and petcock.
- 4. Temperature Control: Self-contained, thermostatic-control valve modulates coolant flow automatically to maintain optimum constant coolant temperature as recommended by engine manufacturer.
- 5. Coolant Hose: Flexible assembly with inside surface of nonporous rubber and outer covering of aging-, UV-, and abrasion-resistant fabric.
 - a. Rating: 50-psig maximum working pressure with coolant at 180 deg F, and noncollapsible under vacuum.
 - b. End Fittings: Flanges or steel pipe nipples with clamps to suit piping and equipment connections.
- F. Muffler/Silencer: Critical type, sized as recommended by engine manufacturer and selected with exhaust piping system to not exceed engine manufacturer's engine backpressure requirements.
 - 1. Minimum sound attenuation of 25 dB at 500 Hz.
 - 2. Sound level measured at a distance of 25 feet from exhaust discharge after installation is complete shall be 78 dBA or less.
- G. Air-Intake Filter: Standard-duty, engine-mounted air cleaner with replaceable dry-filter element and "blocked filter" indicator.
- H. Starting System: 24-V electric, with negative ground.
 - 1. Components: Sized so they are not damaged during a full engine-cranking cycle, with ambient temperature at maximum specified in "Performance Requirements" Article.
 - 2. Cranking Motor: Heavy-duty unit that automatically engages and releases from engine flywheel without binding.
 - 3. Cranking Cycle: As required by NFPA 110 for system level specified.
 - 4. Battery: Lead acid, with capacity within ambient temperature range specified in "Performance Requirements" Article to provide specified cranking cycle at least three times without recharging.
 - 5. Battery Cable: Size as recommended by engine manufacturer for cable length indicated. Include required interconnecting conductors and connection accessories.
 - 6. Battery Compartment: Factory fabricated of metal with acid-resistant finish and thermal insulation. Thermostatically controlled heater shall be arranged to maintain battery above 50 deg F regardless of external ambient temperature within range specified in "Performance Requirements" Article. Include accessories required to support and fasten batteries in place. Provide ventilation to exhaust battery gases.
 - 7. Battery Stand: Factory-fabricated, two-tier metal with acid-resistant finish designed to hold the quantity of battery cells required and to maintain the arrangement to minimize lengths of battery interconnections.
 - 8. Battery-Charging Alternator: Factory mounted on engine with solid-state voltage regulation and 35-A minimum continuous rating.
 - 9. Battery Charger: Current-limiting, automatic-equalizing and float-charging type designed for lead-acid batteries. Unit shall comply with UL 1236 and include the following features:
 - a. Operation: Equalizing-charging rate of 10 A shall be initiated automatically after battery has lost charge until an adjustable equalizing voltage is achieved at battery terminals. Unit shall then be automatically switched to a lower float-charging mode and shall continue to operate in that mode until battery is discharged again.
 - b. Automatic Temperature Compensation: Adjust float and equalize voltages for variations in ambient temperature from minus 40 to 140 deg F to prevent overcharging at high temperatures and undercharging at low temperatures.

- c. Automatic Voltage Regulation: Maintain constant output voltage regardless of input voltage variations up to plus or minus 10 percent.
- d. Ammeter and Voltmeter: Flush mounted in door. Meters shall indicate charging rates.
- e. Safety Functions: Sense abnormally low battery voltage and close contacts providing low battery voltage indication on control and monitoring panel. Sense high battery voltage and loss of ac input or dc output of battery charger. Either condition shall close contacts that provide a battery-charger malfunction indication at system control and monitoring panel.
- f. Enclosure and Mounting: NEMA 250, Type 1, wall-mounted cabinet.

2.5 GASEOUS FUEL SYSTEM

- A. Natural Gas Piping: Comply with requirements in Section 231123 "Facility Natural Gas Piping."
- B. Gas Train: Comply with NFPA 37.
- C. Engine Fuel System:
 - 1. Natural Gas, Vapor-Withdrawal System:
 - a. Carburetor.
 - b. Secondary Gas Regulators: One for each fuel type, with atmospheric vents piped to building exterior.
 - Fuel-Shutoff Solenoid Valves: NRTL-listed, normally closed, safety shutoff valves; one for each fuel source.
 - 2. Fuel Filters: One for each fuel type.
 - 3. Manual Fuel Shutoff Valves: One for each fuel type.
 - 4. Flexible Fuel Connectors: Minimum one for each fuel connection.
 - 5. Fuel change gas pressure switch.

2.6 CONTROL AND MONITORING

- A. Automatic Starting System Sequence of Operation: When mode-selector switch on the control and monitoring panel is in the automatic position, remote-control contacts in one or more separate automatic transfer switches initiate starting and stopping of engine generator. When mode-selector switch is switched to the on position, engine generator starts. The off position of same switch initiates engine generator shutdown. When engine generator is running, specified system or equipment failures or derangements automatically shut down engine generator and initiate alarms.
- B. Provide minimum run-time control set for 30 minutes, with override only by operation of a remote emergency-stop switch.
- C. Comply with UL 508A.
- D. Configuration: Operating and safety indications, protective devices, basic system controls, and engine gages shall be grouped in a common control and monitoring panel mounted on the engine generator. Mounting method shall isolate the control panel from engine generator vibration. Panel shall be powered from the engine generator battery.
- E. Control and Monitoring Panel:

- 1. Digital controller with integrated LCD display, controls, and microprocessor, capable of local and remote control, monitoring, and programming, with battery backup.
- 2. Instruments: Located on the control and monitoring panel and viewable during operation.
 - a. Engine lubricating-oil pressure gage.
 - b. Engine-coolant temperature gage.
 - c. DC voltmeter (alternator battery charging).
 - d. Running-time meter.
 - e. AC voltmeter, for each phase connected to a phase selector switch.
 - f. AC ammeter, for each phase connected to a phase selector switch.
 - g. AC frequency meter.
 - h. Generator-voltage adjusting rheostat.
- 3. Controls and Protective Devices: Controls, shutdown devices, and common visual alarm indication as required by NFPA 110 for Level 1 system, including the following:
 - a. Cranking control equipment.
 - b. Run-Off-Auto switch.
 - c. Control switch not in automatic position alarm.
 - d. Overcrank alarm.
 - e. Overcrank shutdown device.
 - f. Low water temperature alarm.
 - g. High engine temperature pre-alarm.
 - h. High engine temperature.
 - i. High engine temperature shutdown device.
 - j. Overspeed alarm.
 - k. Overspeed shutdown device.
 - l. Low-fuel main tank.
 - 1) Low-fuel-level alarm shall be initiated when the level falls below that required for operation for the duration required for the indicated EPSS class.
 - m. Coolant low-level alarm.
 - n. Coolant low-level shutdown device.
 - o. Coolant high-temperature prealarm.
 - p. Coolant high-temperature alarm.
 - q. Coolant low-temperature alarm.
 - r. Coolant high-temperature shutdown device.
 - s. EPS load indicator.
 - t. Battery high-voltage alarm.
 - u. Low-cranking voltage alarm.
 - v. Battery-charger malfunction alarm.
 - w. Battery low-voltage alarm.
 - x. Lamp test.
 - y. Contacts for local and remote common alarm.
 - z. Low-starting air pressure alarm.
 - aa. Low-starting hydraulic pressure alarm.
 - bb. Remote manual-stop shutdown device.
 - cc. Air shutdown damper alarm when used.
 - dd. Air shutdown damper shutdown device when used.
 - ee. Generator overcurrent-protective-device not-closed alarm.
- F. Connection to Datalink:

- 1. A separate terminal block, factory wired to Form C dry contacts, for each alarm and status indication.
- Provide connections for datalink transmission of indications to remote data terminals via ModBus.
 Data system connections to terminals are covered in Section 260913 "Electrical Power Monitoring and Control."
- G. Common Remote Panel with Common Audible Alarm: Comply with NFPA 110 requirements for Level 1 systems. Include necessary contacts and terminals in control and monitoring panel. Remote panel shall be powered from the engine generator battery.

H. Controller Paralleling Functions:

- 1. The controller shall have two methods of conducting parallel operation to accomplish the synchronizing and paralleling functions:
 - a. Ethernet based communication protocol. This communication methodology shall provide enhanced feature sets of the installed paralleling system, including Feeder Breaker Control and advanced system monitoring and increased load sense demand features.
 - b. Hard Wired. This configuration shall be provided as a redundant connection. This method of connection shall provide separate hard wired lines between paralleled generator sets for each of the featured synchronizing and paralleling functions: Dead Bus Arbitration, Load Sharing and Load Sense Demand.
- 2. Dead Bus Arbitration: The controller shall incorporate true dead bus arbitration to determine and select the primary generator set to close to a dead bus, allowing only one unit to close to the dead bus. The dead bus arbitration control minimizes the time for the first generator set to close to the dead bus.
- 3. Synchronizing: The controller shall monitor all three phases of the generator and main bus. The proprietary synchronizing algorithms drive the generator output frequency, voltage, and phase to match another source, and close the generator circuit breaker when conditions have been met.
- 4. Load Shed/Load Add: The controller shall provide a configurable load add signal as generator set capacity becomes available. In the event of generator capacity becoming unavailable during operation, a configurable load shed signal shall be provided.
- 5. Load Sharing: The controller shall actively monitor the real (kW) and reactive (kVAr) load requirement of all paralleled generator
- 6. sets, and adjusts output of the generator set to maintain a balanced loading of all generator sets.
- 7. Soft Load/Unload: When load sharing, soft loading and soft unloading reduces instability and risk to equipment by increasing or decreasing load in a controlled manner before closing or opening the generator breaker.
- 8. Load Sense/Load Demand: This feature shall be priority based for hard wired load sense/load demand, and capable to be engine hour based with the ethernet based communication protocol connection.
- 9. Feeder breaker control: Feeder breaker control for connecting a generator bus and a load bus shall be included with the controller operation. For this feature set, a programmable digital output is configured for a "Feeder Breaker Close Command" and/or "Feeder Breaker Trip Command" based on minimum real/reactive power required set points. The advanced programming capability of this feature shall allow for the controlled sequencing of multiple load shed/add stages.

I. Modes of Paralleling Operation:

- 1. The controller shall operate as a multi-generator set paralleling controller. Support shall be provided for both emergency standby and prime power operation. Features include automatic paralleling, dead bus arbitration, load sharing, and load sense/load demand.
- 2. Automatic paralleling: The controller shall automatically adjust the voltage and frequency of the generator set. When the generator output is synchronized with the second source, the controller shall close the generator circuit breaker.

- 3. Manual paralleling: The operator shall be able to manually adjust the voltage and frequency of the generator set. When the generator set is synchronized with the second source, the operator can initiate a generator circuit breaker close command. A 3-phase sync check function shall be included to prevent out of phase paralleling.
- 4. Sync check mode: The controller shall automatically adjust the voltage and frequency of the generator set without closing the generator circuit breaker. When the generator set is synchronized with the second source, the operator shall initiate a generator circuit breaker close command. A 3-phase sync check function shall also be included to prevent out of phase paralleling.

J. Sequence of Operation for Normal Conditions:

- 1. Paralleling low-voltage controls, including controlled generators, controlled circuit breakers, other controlled devices, and transfer switches, shall be in the automatic position and ready to operate on loss of power or other designated initiation conditions.
- 2. Each single-generator monitoring and control system has not received a "start" signal from the following:
 - a. Multiple-generator paralleling monitoring and control system.

K. Sequence of Operation for Loss of Normal Power Conditions:

- 1. The paralleling controls shall receive engine start signals from each transfer switch that the generator plant supplies. Each generator shall then receive an engine start signal from the paralleling controls. Simultaneous with this signal, the load shed breakers in the main distribution shall open.
- 2. On receiving a start signal, each single-generator monitoring and control system shall start engine generators and achieve rated voltage and frequency.
- 3. As soon as engines start, generator 1 circuit breaker shall close energizing the load bus. Once generator 2 is within acceptable voltage and frequency limits (90% voltage and 58 Hz), the respective generator breaker shall close.
- 4. Once generator 1 breaker closes in to the bus, the service entrance ATS shall transfer to emergency and feed the respective loads. Once generator 2 breaker closes, the load shed feeder breakers shall close.
- 5. Each single-generator paralleling monitoring and control system synchronizes its associated engine. On closure to isolated paralleling bus, each engine generator assumes its proportional share of total load.
- 6. Failure of an Engine Generator to Synchronize: If an engine generator fails to synchronize, sound an alarm after a preset time delay, but continue to attempt to synchronize the engine generator until signaled to stop by manual operation. Load shed breakers shall be left open if the second generator fails to synchronize to the bus.
- 7. Black-Start Control: Prevent out-of-phase paralleling. After selecting the first generator to achieve 90 percent rated voltage and frequency, inhibit the connection of generator-controlled circuit breakers to the isolated paralleling bus, then close the circuit breaker connecting the first generator to the isolated paralleling bus.
- 8. If engine generator fails to start, after expiration of over-crank time delay, engine generator shuts down and alarm is initiated.
- L. Transfer Switch Return to Normal Condition Sequence of Operation: Enable transfer switch to return to normal power when normal power is available at the transfer switch.

M. Return to Normal Condition Sequence of Operation:

- 1. Process starts on removal of start signals from system.
- 2. When no load remains on isolated paralleling bus, all generator breakers open, go through cool-down period, and shut down.

3. If start signal is received during cool-down period, one engine generator is reconnected to isolated paralleling bus, and system operation follows that of "loss of normal power."

N. System Test Sequence of Operation:

- 1. Configure tests to comply with NFPA 110, Level 1 testing requirements for each generator. Automatically generate NFPA 110, Level 1 reports.
- 2. Single-generator test.
- 3. Multiple-generator test.
- 4. Start generators manually, by generator exerciser on user-defined schedule.
- 5. Engine generator(s) start and achieve rated voltage and frequency.
- 6. Failure of Engine Generator to Start: After expiration of over-crank time delay, engine generator shuts down and alarm is initiated.
- 7. Black-Start Control: Prevent out-of-phase paralleling. After selecting first generator to achieve 90 percent rated voltage and frequency, inhibit connection of generator-controlled circuit breakers to isolated paralleling bus, then close circuit breaker connecting first generator to isolated paralleling bus. Each single-generator paralleling monitoring and control system synchronizes its associated engine generator and allows closure of respective generator paralleling low-voltage circuit breakers to the isolated paralleling bus. On closure to isolated paralleling bus, each engine generator assumes its proportional share of total load.
- 8. Failure of Engine Generator to Synchronize: If engine generator fails to synchronize, sound alarm after preset time delay, but continue to attempt to synchronize engine generator until signaled to stop by manual operation.
- 9. Manually select or automatically preselect whether test is a load or no-load test. If test is a load test, manually select or automatically preselect loads to be transferred according to schedule or by adjustable time delays at transfer switches. After generators are connected to isolated paralleling bus, transfer loads by sending signal to load-add relay that is connected to input for "remote transfer to generator source" of transfer switch controller or to other devices. If test is load-bank test, automatically operate load-bank breaker to connect load bank for testing generators based on number and configuration of generators.
- 10. After adjustable period of time the system, allow engine generators to optimize down to only the required number to be online to avoid wet stacking. Set stopping and starting sequences through human-machine interface panel device and allow settings based on manual priorities or by engine run time.
- 11. On sensing available bus capacity diminished to set point, controller starts and closes engine generators to the isolated paralleling bus to accommodate load.
- 12. After system test is completed, transfer loads back to normal power with transfer switches. Shut down system using sequence in automatic mode.
- 13. If there is an outage during this mode of operation, automatically change to requirements specified in "Sequence of Operation for Loss of Normal Power Conditions", signal any engine generator that is not currently operating to start, and cancel system test.
- O. Remote Alarm Annunciator: Comply with NFPA 99. An LED indicator light labeled with proper alarm conditions shall identify each alarm event, and a common audible signal shall sound for each alarm condition. Silencing switch in face of panel shall silence signal without altering visual indication. Connect so that after an alarm is silenced, clearing of initiating condition will reactivate alarm until silencing switch is reset. Cabinet and faceplate are surface- or flush-mounting type to suit mounting conditions indicated.
 - 1. Overcrank alarm.
 - 2. Coolant low-temperature alarm.
 - 3. High engine temperature pre-alarm.
 - 4. High engine temperature alarm.
 - 5. Low lube oil pressure alarm.
 - 6. Overspeed alarm.

- 7. Low-fuel main tank alarm.
- 8. Low coolant level alarm.
- 9. Low-cranking voltage alarm.
- 10. Contacts for local and remote common alarm.
- 11. Audible-alarm silencing switch.
- 12. Air shutdown damper when used.
- 13. Run-Off-Auto switch.
- 14. Control switch not in automatic position alarm.
- 15. Low-cranking voltage alarm.
- 16. Generator overcurrent-protective-device not-closed alarm.
- P. Supporting Items: Include sensors, transducers, terminals, relays, and other devices and include wiring required to support specified items. Locate sensors and other supporting items on engine or generator unless otherwise indicated.
- Q. Remote Emergency-Stop Switch: Flush; wall mounted unless otherwise indicated; and labeled. Push button shall be protected from accidental operation.

2.7 GENERATOR OVERCURRENT AND FAULT PROTECTION

- A. Overcurrent protective devices for the entire EPSS shall be coordinated to optimize selective tripping when a short circuit occurs. Coordination of protective devices shall consider both utility and EPSS as the voltage source.
 - 1. Overcurrent protective devices for the EPSS shall be accessible only to authorized personnel.
- B. Generator Circuit Breaker: Molded-case, thermal-magnetic type; 100 percent rated; complying with UL 489.
 - 1. Tripping Characteristic: Designed specifically for generator protection.
 - 2. Trip Rating: Matched to generator output rating.
 - 3. Shunt Trip: Connected to trip breaker when engine generator is shut down by other protective devices
 - 4. Mounting: Adjacent to, or integrated with, control and monitoring panel.
- C. Generator Protector: Microprocessor-based unit shall continuously monitor current level in each phase of generator output, integrate generator heating effect over time, and predict when thermal damage of alternator will occur. When signaled by generator protector or other engine generator protective devices, a shunt-trip device in the generator disconnect switch shall open the switch to disconnect the generator from load circuits. Protector performs the following functions:
 - 1. Initiates a generator overload alarm when generator has operated at an overload equivalent to 110 percent of full-rated load for 60 seconds. Indication for this alarm is integrated with other engine generator malfunction alarms. Contacts shall be available for load shed functions.
 - 2. Under single- or three-phase fault conditions, regulates generator to 300 percent of rated full-load current for up to 10 seconds.
 - 3. As overcurrent heating effect on the generator approaches the thermal damage point of the unit, protector switches the excitation system off, opens the generator disconnect device, and shuts down the engine generator.
 - 4. Senses clearing of a fault by other overcurrent devices and controls recovery of rated voltage to avoid overshoot.

- D. Ground-Fault Indication: Comply with NFPA 70 Article 700, "Emergency System" signals for ground fault.
 - 1. Indicate ground fault with other engine generator alarm indications.
 - 2. Trip generator protective device on ground fault.

2.8 GENERATOR, EXCITER, AND VOLTAGE REGULATOR

- A. Comply with NEMA MG 1.
- B. Drive: Generator shaft shall be directly connected to engine shaft. Exciter shall be rotated integrally with generator rotor.
- C. Electrical Insulation: Class H or Class F.
- D. Stator-Winding Leads: Brought out to terminal box to permit future reconnection for other voltages if required. Provide 12-lead alternator.
- E. Range: Provide extended range of output voltage by adjusting the excitation level.
- F. Construction shall prevent mechanical, electrical, and thermal damage due to vibration, overspeed up to 125 percent of rating, and heat during operation at 110 percent of rated capacity.
- G. Enclosure: Dripproof.
- H. Instrument Transformers: Mounted within generator enclosure.
- I. Voltage Regulator: Solid-state type, separate from exciter, providing performance as specified and as required by NFPA 110.
 - 1. Adjusting Rheostat on Control and Monitoring Panel: Provide plus or minus 5 percent adjustment of output-voltage operating band.
 - 2. Maintain voltage within 15 percent on one step, full load.
 - 3. Provide anti-hunt provision to stabilize voltage.
 - 4. Maintain frequency within 10 percent and stabilize at rated frequency within five seconds.
- J. Strip Heater: Thermostatically controlled unit arranged to maintain stator windings above dew point.
- K. Windings: Two-thirds pitch stator winding and fully linked amortisseur winding.
- L. Subtransient Reactance: 12 percent, maximum.

2.9 OUTDOOR ENGINE GENERATOR ENCLOSURE

- A. Description: Vandal-resistant, sound-attenuating, weatherproof aluminum housing, wind resistant up to 100 mph. Multiple panels shall be lockable and provide adequate access to components requiring maintenance. Panels shall be removable by one person without tools. Instruments and control shall be mounted within enclosure.
 - 1. Sound Attenuation Level: 65 dBA at 23 Feet.

- B. Description: Walk-in type with 2.5 ft space between engine and side walls for maintenance accessibility. Rectangular construction with no air scoops, rooftop pitched rooftop, EPDM membrane covered.; erected on concrete foundation. Slip proof steel flooring. Ambient conditions: -20F to 110F.
- C. 100A load panel, pre-wired for powering and control of all generator set accessories.
- D. Structural Design and Anchorage: Comply with ASCE/SEI 7 for wind loads up to 100 mph.
- E. Seismic Design: Comply with seismic requirements in Section 260548.16 "Seismic Controls for Electrical Systems."
- F. Hinged Doors: With padlocking provisions.
- G. Space Heater: Thermostatically controlled and sized to prevent condensation.
- H. Lighting: Provide weather-resistant LED lighting with 30 fc average maintained.
- I. Thermal Insulation: Manufacturer's standard materials and thickness selected in coordination with space heater to maintain winter interior temperature within operating limits required by engine generator components.
- J. Muffler Location: Within enclosure.
- K. Engine-Cooling Airflow through Enclosure: Maintain temperature rise of system components within required limits when unit operates at 110 percent of rated load for two hours with ambient temperature at top of range specified in system service conditions.
 - 1. Automatic Dampers: At engine cooling-air inlet and discharge. Dampers shall be closed to reduce enclosure heat loss in cold weather when unit is not operating.
 - 2. Ventilation: Provide temperature-controlled exhaust fan interlocked to prevent operation when engine is running.
- L. Interior Lights with Switch: Factory-wired, vaporproof luminaires within housing; arranged to illuminate controls and accessible interior. Arrange for external electrical connection.
 - 1. AC lighting system and connection point for operation when remote source is available.
 - 2. DC lighting system for operation when remote source and generator are both unavailable.
- M. Convenience Outlets: Factory-wired, GFCI. Arrange for external electrical connection.

2.10 VIBRATION ISOLATION DEVICES

- A. Elastomeric Isolator Pads: Oil- and water-resistant elastomer or natural rubber, arranged in single or multiple layers, molded with a nonslip pattern and galvanized-steel baseplates of sufficient stiffness for uniform loading over pad area, and factory cut to sizes that match requirements of supported equipment.
 - 1. Material: Standard neoprene separated by steel shims.
 - 2. Number of Layers: Three.
 - 3. Minimum Deflection: 1 inch.
- B. Restrained Spring Isolators: Freestanding, steel, open-spring isolators with seismic restraint.
 - 1. Housing: Steel with resilient vertical-limit stops to prevent spring extension due to wind loads or if weight is removed; factory-drilled baseplate bonded to 1/4-inch-thick, elastomeric isolator pad

- attached to baseplate underside; and adjustable equipment-mounting and -leveling bolt that acts as blocking during installation.
- 2. Outside Spring Diameter: Not less than 80 percent of compressed height of the spring at rated load.
- 3. Minimum Additional Travel: 50 percent of required deflection at rated load.
- 4. Lateral Stiffness: More than 80 percent of rated vertical stiffness.
- 5. Overload Capacity: Support 200 percent of rated load, fully compressed, without deformation or failure.
- 6. Minimum Deflection: 1 inch.
- C. Comply with requirements in Section 232116 "Hydronic Piping Specialties" for vibration isolation and flexible connector materials for steel piping.
- D. Comply with requirements in Section 233113 "Metal Ducts" for vibration isolation and flexible connector materials for exhaust shroud and ductwork.
- E. Vibration isolation devices shall not be used to accommodate misalignments or to make bends.

2.11 FINISHES

A. Indoor and Outdoor Enclosures and Components: Manufacturer's standard finish over corrosion-resistant pretreatment and compatible primer.

2.12 SOURCE QUALITY CONTROL

- A. Prototype Testing: Factory test engine generator using same engine model, constructed of identical or equivalent components and equipped with identical or equivalent accessories.
 - 1. Tests: Comply with NFPA 110, Level 1 Energy Converters and with IEEE 115.
- B. Project-Specific Equipment Tests: Before shipment, factory test engine generator and other system components and accessories manufactured specifically for this Project. Perform tests at rated load and power factor. Include the following tests:
 - 1. Test components and accessories furnished with installed unit that are not identical to those on tested prototype to demonstrate compatibility and reliability.
 - 2. Test generator, exciter, and voltage regulator as a unit.
 - 3. Full-load run.
 - 4. Maximum power.
 - 5. Voltage regulation.
 - 6. Transient and steady-state governing.
 - 7. Single-step load pickup.
 - 8. Safety shutdown.
 - 9. Provide 14 days' advance notice of tests and opportunity for observation of tests by Owner's representative.
 - 10. Report factory test results within 10 days of completion of test.

PART 3 - EXECUTION

3.1 EXAMINATION

- A. Examine areas, equipment bases, and conditions, with Installer present, for compliance with requirements for installation and other conditions affecting packaged engine generator performance.
- B. Examine roughing-in for piping systems and electrical connections to verify actual locations of connections before packaged engine generator installation.
- C. Proceed with installation only after unsatisfactory conditions have been corrected.

3.2 INSTALLATION

- A. Comply with NECA 1 and NECA 404.
- B. Comply with packaged engine generator manufacturers' written installation and alignment instructions and with NFPA 110.

C. Equipment Mounting:

- 1. Install packaged engine generators on cast-in-place concrete equipment bases. Comply with requirements for equipment bases and foundations specified in Section 033000 "Cast-in-Place Concrete."
- 2. Coordinate size and location of concrete bases for packaged engine generators. Cast anchor-bolt inserts into bases. Concrete, reinforcement, and formwork requirements are specified with concrete.
- Install packaged engine generator with elastomeric isolator pads having a minimum deflection of 1 inch on 4-inch-high concrete base. Secure enclosure to anchor bolts installed in concrete bases. Concrete base construction is specified in Section 260548.16 "Seismic Controls for Electrical Systems."
- D. Install packaged engine generator to provide access, without removing connections or accessories, for periodic maintenance.
- E. Exhaust System: Install Schedule 40 black steel piping with welded joints and connect to engine muffler. Install thimble at wall. Piping shall be same diameter as muffler outlet.
 - 1. Install flexible connectors and steel piping materials according to requirements in Section 232116 "Hydronic Piping Specialties."
 - 2. Insulate muffler/silencer and exhaust system components according to requirements in Section 230719 "HVAC Piping Insulation."
 - 3. Install isolating thimbles where exhaust piping penetrates combustible surfaces with a minimum of 9 inches of clearance from combustibles.
- F. Drain Piping: Install condensate drain piping to muffler drain outlet with a shutoff valve, stainless-steel flexible connector, and Schedule 40 black steel pipe with welded joints.

G. Gaseous Fuel Piping:

1. Natural gas piping, valves, and specialties for gas distribution are specified in Section 231123 "Facility Natural Gas Piping."

H. Electrical Wiring: Install electrical devices furnished by equipment manufacturers but not specified to be factory mounted.

3.3 CONNECTIONS

- A. Piping installation requirements are specified in other Sections. Drawings indicate general arrangement of piping and specialties.
- B. Connect fuel, cooling-system, and exhaust-system piping adjacent to packaged engine generator to allow service and maintenance.
- C. Connect engine exhaust pipe to engine with flexible connector.
- D. Gaseous Fuel Connections:
 - 1. Connect fuel piping to engines with a gate valve and union and flexible connector.
 - 2. Install manual shutoff valve in a remote location to isolate gaseous fuel supply to the generator.
 - 3. Vent gas pressure regulators outside building a minimum of 60 inches from building openings.
- E. Ground equipment according to Section 260526 "Grounding and Bonding for Electrical Systems."
- F. Connect wiring according to Section 260519 "Low-Voltage Electrical Power Conductors and Cables." Provide a minimum of one 90-degree bend in flexible conduit routed to the engine generator from a stationary element.
- G. Balance single-phase loads to obtain a maximum of 10 percent unbalance between any two phases.

3.4 IDENTIFICATION

- A. Identify system components according to Section 230553 "Identification for HVAC Piping and Equipment" and Section 260553 "Identification for Electrical Systems."
- B. Install a sign indicating the generator neutral is bonded to the main service neutral at the main service location.

3.5 FIELD QUALITY CONTROL

- A. Manufacturer's Field Service: Engage a factory-authorized service representative to test and inspect components, assemblies, and equipment installations, including connections.
- B. Perform tests and inspections with the assistance of a factory-authorized service representative.
- C. Tests and Inspections:
 - 1. Perform tests recommended by manufacturer and each visual and mechanical inspection and electrical and mechanical test listed in first two subparagraphs below, as specified in NETA ATS. Certify compliance with test parameters.
 - a. Visual and Mechanical Inspection:

- 1) Compare equipment nameplate data with Drawings and the Specifications.
- 2) Inspect physical and mechanical condition.
- 3) Inspect anchorage, alignment, and grounding.
- 4) Verify that the unit is clean.

b. Electrical and Mechanical Tests:

- 1) Perform insulation-resistance tests according to IEEE 43.
 - a) Machines Larger Than 200 hp Test duration shall be 10 minutes. Calculate polarization index.
 - b) Machines 200 hp or Less: Test duration shall be one minute. Calculate the dielectric-absorption ratio.
- 2) Test protective relay devices.
- 3) Verify phase rotation, phasing, and synchronized operation as required by the application.
- 4) Functionally test engine shutdown for low oil pressure, overtemperature, overspeed, and other protection features as applicable.
- 5) Perform vibration test for each main bearing cap.
- 6) Conduct performance test according to NFPA 110.
- 7) Verify correct functioning of the governor and regulator.
- 2. NFPA 110 Acceptance Tests: Perform tests required by NFPA 110 that are additional to those specified here including, but not limited to, single-step full-load pickup test.
- 3. Battery Tests: Equalize charging of battery cells according to manufacturer's written instructions. Record individual cell voltages.
 - Measure charging voltage and voltages between available battery terminals for full-charging and float-charging conditions. Check electrolyte level and specific gravity under both conditions.
 - b. Test for contact integrity of all connectors. Perform an integrity load test and a capacity load test for the battery.
 - c. Verify acceptance of charge for each element of the battery after discharge.
 - d. Verify that measurements are within manufacturer's specifications.
- 4. Battery-Charger Tests: Verify specified rates of charge for both equalizing and float-charging conditions.
- 5. System Integrity Tests: Methodically verify proper installation, connection, and integrity of each element of engine generator system before and during system operation. Check for air, exhaust, and fluid leaks
- 6. Exhaust-System Back-Pressure Test: Use a manometer with a scale exceeding 40-inch wg. Connect to exhaust line close to engine exhaust manifold. Verify that back pressure at full-rated load is within manufacturer's written allowable limits for the engine.
- 7. Exhaust Emissions Test: Comply with applicable government test criteria.
- 8. Voltage and Frequency Transient Stability Tests: Use recording oscilloscope to measure voltage and frequency transients for 50 and 100 percent step-load increases and decreases, and verify that performance is as specified.
- 9. Harmonic-Content Tests: Measure harmonic content of output voltage at 25 and 100 percent of rated linear load. Verify that harmonic content is within specified limits.
- 10. Noise Level Tests: Measure A-weighted level of noise emanating from engine generator installation, including engine exhaust and cooling-air intake and discharge, at four locations 25 feet from edge of the generator enclosure on the property line, and compare measured levels with required values.

- D. Coordinate tests with tests for transfer switches and run them concurrently.
- E. Test instruments shall have been calibrated within the past 12 months, traceable to NIST Calibration Services, and adequate for making positive observation of test results. Make calibration records available for examination on request.
- F. Leak Test: After installation, charge exhaust, coolant, and fuel systems and test for leaks. Repair leaks and retest until no leaks exist.
- G. Operational Test: After electrical circuitry has been energized, start units to confirm proper motor rotation and unit operation for generator and associated equipment.
- H. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
- I. Remove and replace malfunctioning units and retest as specified above.
- J. Retest: Correct deficiencies identified by tests and observations, and retest until specified requirements are met
- K. Report results of tests and inspections in writing. Record adjustable relay settings and measured insulation resistances, time delays, and other values and observations. Attach a label or tag to each tested component indicating satisfactory completion of tests.
- L. Infrared Scanning: After Substantial Completion, but not more than 60 days after final acceptance, perform an infrared scan of each power wiring termination and each bus connection while running with maximum load. Remove all access panels, so terminations and connections are accessible to portable scanner.
 - 1. Follow-up Infrared Scanning: Perform an additional follow-up infrared scan 11 months after date of Substantial Completion.
 - 2. Instrument: Use an infrared scanning device designed to measure temperature or to detect significant deviations from normal values. Provide calibration record for device.
 - 3. Record of Infrared Scanning: Prepare a certified report that identifies terminations and connections checked and that describes scanning results. Include notation of deficiencies detected, remedial action taken, and observations after remedial action.

3.6 MAINTENANCE SERVICE

A. Initial Maintenance Service: Beginning at Substantial Completion, maintenance service shall include 12 months' full maintenance by skilled employees of manufacturer's authorized service representative. Include quarterly preventive maintenance and exercising to check for proper starting, load transfer, and running under load. Include routine preventive maintenance as recommended by manufacturer and adjusting as required for proper operation. Parts shall be manufacturer's authorized replacement parts and supplies.

3.7 DEMONSTRATION

A. Engage a factory-authorized service representative to train Owner's maintenance personnel to adjust, operate, and maintain packaged engine generators.

END OF SECTION 263213.16